

## 10k Diesel EGR Valve Cleaner

200ml Aero

### PRODUCT DESCRIPTION

10K Boost Diesel EGR Valve Cleaner is designed to remove harmful deposits that cause the valve to stick and become ineffective. Diesel EGR Valve Cleaner will clean the entire intake system restoring power and performance. Safe for use on vehicles fitted with air mass meters, turbos, catalytic converters and diesel particulate filters.

### PRODUCT BENEFITS

- \* Releases sticking EGR valves
- \* Cleans entire air intake system
- \* Restores power & performance



\* Image for illustrative purposes only.

SIZE	PART NO	BARCODE
200ml Aero	1438	5020618014386



# 10k Diesel EGR Valve Cleaner

200ml Aero

## DIRECTIONS FOR USE

Important: please follow closely all the instructions.

Warning- If at any time during the treatment process the rpm does not increase during application, stop the process and consult a vehicle technician.

1. Warm engine to normal running temperature.
  2. Remove air filter from the filter housing.
  3. Allow the engine to idle.
  4. Attach the extension tube to the nozzle making sure that the nozzle is pointing into the air intake manifold and spray using one second bursts. After each burst allow the engine to idle normally. During application the engine revs may vary and diesel knocking may increase, this is caused by a change in the fuel/air mixture - occasionally raise the revs to between 1000 & 1500 rpm for a few seconds then allow the engine to idle as normal before repeating the application. DO NOT increase the revs when rpm drops!
  5. Repeat the process until the entire can is used.
  6. Allow the engine to idle for 5 minutes once the treatment is completed.
  7. Turn off the engine and re-fit the air filter taking care as the engine will be hot.
  8. Drive the vehicle for 5 to 15 km, but do not rev above 3000 rpm.
  9. Before turning off the engine allow the engine to idle for 2 minutes.
- DO NOT exceed 1500 rpm during application. Avoid contact with paintwork - in the event the product does come into contact with vehicle paintwork - immediately rinse with plenty of water.
- Treat engine every 10,000km. For high mileage vehicles or engines with a constantly sticking EGR valve a second treatment may be required.

## DOSAGE INFORMATION

Treat engine every 10,000km

## STORAGE INSTRUCTIONS

Store in a cool, dry place

## SHELF LIFE

2 years from date of manufacture.

<b>Appearance</b>	: Clear
<b>Odour</b>	: Characteristic
<b>Specific Gravity</b>	: 0.83



# 10k Diesel EGR Valve Cleaner

200ml Aero

**Solubility** : Insoluble in water

**Flammability** : Highly flammable

## **SAFETY PRECAUTIONS**

Please see our latest EC Safety Data Sheets for details.

## **TRANSPORT CLASSIFICATION**

Please see our latest EC Safety Data Sheets for details.

